


# SUPCO SDF-88



|    |       |                          |    |        |                         |
|----|-------|--------------------------|----|--------|-------------------------|
| 01 | M6x45 | HD. SCREW                | 43 | CA-05  | END CAP                 |
| 02 | WS-10 | SPRING WASHER M6         | 44 | WS-28  | MAGAZINE GUARD A        |
| 03 | M6x25 | HD. SCREW                | 45 | WS-27  | MAGAZINE GUARD B        |
| 04 | WS-11 | SPRING WASHER M6         | 46 | VS-09  | VALVE PLUNGER           |
| 05 | CA-04 | BODY CAP                 | 47 | SM-15  | SPRING PIN              |
| 06 | WS-12 | GASKET A                 | 48 | HC5x16 | HC. SCREW               |
| 07 | WS-13 | GASKET B                 | 49 | SP-19  | SPRING                  |
| 08 | PV-07 | EXHAUST PIPE             | 50 | ST-14  | CONTACT ARM             |
| 09 | WS-14 | GASKET C                 | 51 | M5     | NUT                     |
| 10 | PV-16 | EXHAUST VALVE            | 52 | SP-20  | SPRING                  |
| 11 | PV-06 | POPPET VALVE             | 53 | OR-44  | O-RING                  |
| 12 | OR-36 | PISTON O-RING            | 56 | OR-45  | O-RING                  |
| 13 | PS-42 | PISTON & DRIVER ASSEMBLY | 57 | TG-10  | TRIGGER                 |
| 14 | M6    | NUT                      | 59 | ES-08  | VALVE PACKING           |
| 15 | OR-37 | CYLINDER PLATE O-RING    | 60 | SP-21  | SPRING                  |
| 16 | OR-38 | CYLINDER PLATE O-RING    | 61 | FC-13  | VALVE PLATE             |
| 17 | CY-08 | CYLINDER PLATE           | 62 | VS-12  | TRIGGER VALVE BUSHING   |
| 18 | OR-39 | CYLINDER O-RING          | 63 | VS-13  | TRIGGER PLUNGER         |
| 19 | CY-07 | CYLINDER                 | 64 | FC-25  | NAIL RAIL               |
| 20 | OR-40 | CYLINDER O-RING          | 65 | M5x20  | HD. SCREW               |
| 21 | OR-41 | CHECK VALVE O-RING       | 66 | WS-01  | WASHER                  |
| 22 | SP-17 | SPRING                   | 67 | HR-26  | HANGER                  |
| 23 | WS-15 | BASE WASHER              | 68 | M5     | NUT                     |
| 24 | CY-09 | CYLINDER GUIDE           | 69 | WS-07  | WASHER                  |
| 25 | ES-07 | PACKING A                | 70 | M4x25  | HD. SCREW               |
| 26 | BD-18 | BODY                     | 71 | FC-26  | STOP LEVER              |
| 27 | OR-42 | BODY O-RING              | 72 | SM-20  | COLLAR                  |
| 28 | BP-06 | BUMPER                   | 73 | SP-22  | SPRING                  |
| 29 | FD-28 | NAIL FEEDER              | 74 | BH6x12 | BH. SCREW               |
| 30 | SM-17 | SPRING RETAINER          | 77 | OR-22  | O-RING                  |
| 31 | SP-18 | PLATE SPRING             | 78 | FC-27  | BRACKET                 |
| 32 | SM-18 | SPRING SLEEVE            | 79 | WS-26  | WASHER                  |
| 33 | SM-19 | ROLLER                   | 82 | MZ-38  | MZASS MAGAZINE ASSEMBLY |
| 34 | M4    | NUT                      | 84 | ST-15  | FLUSH DRIVE ATTACHMENT  |
| 35 | M5x10 | HD. SCREW                | 87 | VS-31  | VALVE BUSHING           |
| 36 | SM-31 | SPRING PIN               | 88 | SP-45  | SPRING                  |
| 37 | MZ-37 | MAGAZINE                 | 89 | VS-40  | SEQ. ASSY.              |
| 38 | P-23  | NOSE                     | 90 | VS-41  | SAFETY PLUNGER          |
| 39 | WS-17 | SPRING WASHER            | 91 | ST-85  | DEPTH ADJ. SAFETY       |
| 40 | M8x25 | HD. SCREW                |    |        |                         |
| 41 | M6x16 | HD. SCREW                |    |        |                         |
| 42 | OR-43 | CAP O-RING               |    |        |                         |